
siena GARDEN

Istruzioni di montaggio
Assembly instructions



GRANITO base per ombrellone

con maniglia telescopica

40 kg | 50 kg

IT: Trovi queste istruzioni di montaggio in altre lingue su:
GB: You can find these assembly instructions in other languages at:
FR: Vous pouvez trouver ces instructions de montage dans d'autres langues sur:
ES: Puede encontrar estas instrucciones de montaje en otros idiomas en:
NL: U vindt deze montage-instructies in andere talen op:
PL: Instrukcje montazu w innych językach mozna znaleźć pod adresem:
CZ: Tyto montažní pokyny v jinŷch jazycich najdete na:
SK: Tento montaźny navod v inŷch jazykoch najdete na:
RO: Puteti găsi aceste instructiuni de asamblare în alte limbi la:
SE: Du kan hitta dessa monteringsanvisningar pâ andra sprâk pa:
HU: Ezeket az osszeszerelesi utasitasoka: mas nyelveken is megtalalja:

www.sienagarden.de/aufbauanleitungen

Indice | Contents

IT – Istruzioni di montaggio 4

Avvertenze d'uso e di sicurezza. 4

Dati tecnici 6

Contenuto della confezione 7

Istruzioni di montaggio 8

Funzioni 10

Istruzioni per la cura 12

GB – Assembly instructions 14

Safety and usage instructions 14

Technical specifications. 16

Parts list 17

Assembly instructions. 18

Features. 20

Care instructions 22

Prima di iniziare il montaggio, leggi attentamente tutte le avvertenze generali.

Please read all general instructions carefully before starting assembly.

IT – Istruzioni di montaggio

Avvertenze d'uso e di sicurezza

Per goderti a lungo la tua base per ombrellone e usarla in sicurezza, prima del primo utilizzo prenditi un momento per leggere attentamente queste avvertenze.

NOTA: conserva le istruzioni in un luogo sicuro!

- Leggi attentamente tutte le istruzioni prima di usare il prodotto. Così potrai usarlo in modo sicuro e corretto.
- Rispetta tutte le avvertenze di sicurezza per non mettere in pericolo te stesso e gli altri.
- Conserva bene le istruzioni per poterle consultare rapidamente in caso di necessità.
- Se cedi o vendi la base per ombrellone, consegna anche queste istruzioni.
- Usa la base per ombrellone solo se sei in forma e attento. In caso di stanchezza, malattia o sotto l'effetto di alcol, farmaci o droghe, evita di usarla.
- La base per ombrellone non è destinata a persone (ad es. bambini o persone con limitazioni) che non sono in grado di usarla in sicurezza, a meno che non siano sorvegliate o istruite.
- Usa la base per ombrellone solo se in perfette condizioni. In caso di danni o difetti non usarla più e smaltiscila correttamente.
- Usa la base per ombrellone solo per lo scopo previsto e non sovraccaricarla.
- Controlla regolarmente che la base per ombrellone non presenti danni visibili.
- Rispetta le norme di sicurezza, sanitarie e di lavoro vigenti nel tuo paese.
- Se non riesci a risolvere un guasto da solo, rivolgiti direttamente a SIENA GARDEN. Tieni presente che riparazioni improprie fanno decadere il diritto alla garanzia e possono comportare costi aggiuntivi.

Avvertenze di sicurezza specifiche del prodotto

- Posiziona la base per ombrellone solo su una superficie idonea, stabile e portante. Assicurati che la posizione sia sicura e che la base sia ben stabile.

- Durante l'apertura e la chiusura della leva di bloccaggio rapido non mettere le mani nella zona del meccanismo di serraggio. Tieni i bambini lontani dal meccanismo.
- Prima di ogni utilizzo assicurati che il palo sia completamente inserito e bloccato.
- Prima di rimuovere il palo, rimuovi l'ombrellone dal supporto.
- Trasporta la base per ombrellone solo senza ombrellone montato.
- Quando sposti la base per ombrellone, fai attenzione a ostacoli, gradini e pendenze.
- Il notevole peso proprio può causare lesioni in caso di uso improprio.
- Usa questa base per ombrellone in granito solo con ombrelloni a palo centrale.
- Durante il montaggio non lasciare mai la base per ombrellone in posizione verticale incustodita: se cade, può causare gravi lesioni.
- Tieni presente che, a seconda della forza del vento e del diametro dell'ombrellone, la base potrebbe non essere proporzionata in modo ottimale e risultare troppo piccola.
- Chiudi l'ombrellone quando si alza il vento.
- Non lasciare il materiale d'imballaggio incustodito. Può essere pericoloso per i bambini e va quindi sempre smaltito o conservato in modo sicuro.
- Per domande a cui queste istruzioni non rispondono, rivolgiti a noi o a un tecnico qualificato nella tua zona.

Uso previsto

- A seconda della versione, la base per ombrellone in granito è adatta per ombrelloni con un diametro del palo di massimo 48 mm.
- La base per ombrellone in granito è destinata esclusivamente all'uso privato.
- Posiziona sempre la base per ombrellone su una superficie piana, stabile e portante.
- Prima dell'uso leggi attentamente le avvertenze di sicurezza.

Uso improprio ed esclusione di responsabilità

- Usa la base per ombrellone in granito solo come descritto nelle istruzioni. Qualsiasi altro uso è considerato improprio e può causare danni a persone o cose.
- In caso di uso improprio della base per ombrellone, SIENA GARDEN non si assume alcuna responsabilità per eventuali danni. In tal caso il rischio è esclusivamente a carico dell'utente o del gestore.


Dati tecnici

Tabella riepilogativa dei prodotti


GRANITO base ombrellone	40 kg	50 kg
rotonda	Y15225	Y17843
quadrata	Y17844	Y17842

Dimensioni del prodotto


40 kg rotonda




50 kg rotonda



40 kg quadrata




50 kg quadrata




Contenuto della confezione

AVVERTENZA: Pericolo di soffocamento: tieni i materiali d'imballaggio lontano dai bambini. Non usarli come giocattolo.

Questi componenti dovrebbero essere presenti nella confezione. Verifica che siano completi e integri.



A: 1 ×
Base per ombrellone in granito



B: 1 ×
Palo



C: 1 ×
Anello adattatore



D: 4 ×
Adattatori
32 mm



E: 4 ×
Adattatori
38 mm




F: 4 ×
Adattatori
48 mm




G: 1 ×
Chiave a brugola

Istruzioni di montaggio


1. Posiziona il palo sopra l'apertura della lastra di granito e inseriscilo in verticale.



2. Ruota il palo finché non si innesta nel sistema twist-lock ed è saldamente collegato alla lastra di granito. Per semplificare, puoi orientare orizzontalmente la maniglia del palo per fare leva.




3. Ora verifica che il palo sia ben fissato e non si possa più staccare dalla piastra di base. Controlla anche che i piedini sul lato inferiore poggino saldamente. Se necessario, puoi svitarli per compensare le irregolarità.




Funzioni


1. Solleva la maniglia del palo e inserisci l'asta dell'ombrellone nel palo. Assicurati che le piastrine adattatrici siano della misura giusta per una tenuta ottimale. Si inseriscono e si estraggono facilmente dall'anello adattatore.



2. Abbassa di nuovo la maniglia e stringi la vite al centro della maniglia finché l'asta dell'ombrellone non è saldamente fissata nel palo.



3. Per sbloccare il palo, rimuovi prima l'ombrellone dal supporto. Poi premi il pulsante alla base del palo e ruota il palo in senso antiorario.



Istruzioni per la cura

Pulizia e cura

- Prima della pulizia, rispetta anche le avvertenze di sicurezza.
- Rimuovi i depositi di sporco e pulisci regolarmente la base per ombrellone in granito con acqua tiepida e/o sapone neutro.
- Evita l'uso di acidi aggressivi, aceto o detergenti abrasivi.
- Controlla regolarmente che tutti i collegamenti a vite siano ben serrati e stringili se necessario.
- Quando non la usi o in inverno, conserva la base per ombrellone in granito in un luogo asciutto.

Smaltimento

Smaltimento del prodotto
- Al termine della sua vita utile, smaltisci la base per ombrellone in granito secondo le norme locali vigenti.
- Separa i singoli materiali, come granito, parti in metallo e in plastica, e avviali al riciclo, ove possibile.
- Non smaltire il prodotto con i rifiuti domestici.
- Per informazioni sulle possibilità di smaltimento e riciclo adeguate, rivolgiti all'ente di smaltimento locale.

Smaltimento dell'imballaggio
- L'imballaggio è in cartone, che può essere riciclato.
- Avvia questi materiali al riciclo.

Assistenza clienti e supporto

In caso di problemi, domande o necessità di ricambi, contattaci:
SIENA GARDEN GmbH & Co. KG
Tel. : +49 251 687 - 6040
E-Mail: **service@sienagarden.de**
www.sienagarden.de
Tieni a portata di mano il numero di serie e una foto del problema.

GB – Assembly instructions

Safety and usage instructions

To ensure that you can enjoy your parasol base for a long time and use it safely, please take a moment to read these instructions carefully before first use.

NOTE: Keep these operating instructions in a safe place!

- Please read the entire manual carefully before using the product so that you can use it safely and correctly.
- Follow all safety instructions to avoid putting yourself or others at risk.
- Keep these instructions in a safe place so that you can quickly refer to them whenever necessary.
- If you give away or sell the parasol base, please include these instructions as well.
- Only use the parasol base when you are fit and alert. Do not use it if you are tired, ill, or under the influence of alcohol, medication, or drugs.
- The parasol base is not intended for use by persons (e. g. children or individuals with reduced physical, sensory, or mental capabilities) who are unable to operate it safely, unless they are supervised or instructed by a responsible person.
- Use the parasol base only when it is in perfect condition. If it is damaged or defective, discontinue use and dispose of it properly.
- Use the parasol base only for its intended purpose and do not overload it.
- Regularly inspect the parasol base for visible signs of damage.
- Observe all applicable safety, health, and workplace regulations in your country.
- If you cannot rectify a fault yourself, please contact SIENA GARDEN directly. Please note that improper repairs may void the warranty and could result in additional costs.

Product-Specific Safety Instructions

- Only place the parasol base on a suitable, stable, and load-bearing surface. Ensure that the location is safe and that the parasol base stands securely.
- Keep hands and fingers clear of the clamping mechanism during operation of the quick-release clamp. Keep children away from the mechanism.
- Before each use, verify that the support tube is correctly installed and locked.
- The parasol must be removed before the support tube is detached from the

base.

- Transport the parasol base only when no parasol is installed.
- Exercise caution when moving the parasol base over obstacles, steps, or inclined surfaces.
- Due to its substantial weight, improper handling of the parasol base may cause personal injury.
- Use this granite parasol base only with center-pole parasols.
- Never leave the parasol base standing upright unattended during assembly. If it falls over, it may cause serious injury.
- Please note that, depending on the wind conditions and the diameter of the parasol, the parasol base may not be optimally sized and could be too small to provide sufficient stability.
- Close the parasol when wind arises.
- Do not leave packaging materials lying around carelessly. They may pose a danger to children and should always be disposed of or stored safely.
- If you still have questions that are not answered in these instructions, please contact us or a qualified specialist in your area.

Intended Use

- Depending on the model, the granite parasol base is suitable for parasols with a pole diameter of up to 48 mm.
- The granite parasol base is intended for private use only.
- The parasol base is not suitable for commercial use.
- Always place the parasol base on a level, stable, and load-bearing surface.
- Read the safety instructions carefully before use.

Improper Use and Disclaimer of Liability

- Use the granite parasol base only as described in these instructions. Any other use is considered improper and may result in personal injury or property damage.
- If the product is not used as intended, SIENA GARDEN accepts no liability for any resulting damage. In such cases, the risk rests solely with the user or operator.


Technical specifications

Chart for an overview of the products


PRODUCT name	40 kg	50 kg
round	Y15225	Y17843
square	Y17844	Y17842

Product dimensions


40 kg round




50 kg round



40 kg square




50 kg square




Parts list

WARNING: Choking hazard: Keep packaging materials away from children. Do not use as toys.

These parts should be included in the package.
Please check them for completeness and integrity.



A: 1 ×
granite parasol base



B: 1 ×
base tube



C: 1 ×
adapter ring



D: 4 ×
adapter plates
32 mm



E: 4 ×
adapter plates
38 mm




F: 4 ×
adapter plates
48 mm




G: 1 ×
allen key

Assembly instructions


1. Align the base tube with the receiving opening in the granite base and insert it vertically.



2. Rotate the base tube until it engages in the twist-lock system and is securely locked to the granite base. To make this easier, you can position the handle of the pole tube horizontally to create additional leverage.




3. Ensure that the tube is firmly secured and cannot be removed from the base plate. Check that the feet on the underside are stable. If required, adjust them by screwing them out to level the umbrella base on uneven surfaces.




Features


1. Raise the handle of the support tube and insert the parasol pole into the tube. Make sure to use the correct size of adapter plates for optimum support.



2. Lower the handle back down and tighten the screw in the center of the handle until the parasol pole is securely clamped in the base tube.



3. To remove the base tube, first take the parasol out of the holder. Then press down the button at the base of the tube and rotate the support tube counterclockwise.



Care instructions

Cleaning and care

- Please observe the safety instructions before cleaning.
- Remove dirt deposits and clean your granite parasol base regularly using lukewarm water and/or mild soap.
- Avoid using aggressive acids, vinegar, or abrasive cleaning agents.
- Regularly check all screw connections to ensure they are tight and retighten them if necessary.
- Store your granite parasol base in a dry place when not in use or during the winter.

Disposal

Product Disposal

- At the end of its service life, dispose of the granite parasol base in accordance with applicable local regulations
- Separate the individual materials, such as granite, metal, and plastic components, and recycle them wherever possible.
- Do not dispose of the product with household waste.
- For information on appropriate disposal and recycling options, contact your local waste disposal authority.

Packaging Disposal

- The packaging is made of cardboard and other recyclable materials.
- Dispose of the packaging materials through the appropriate recycling collection systems.
- Please separate the packaging materials by type and recycle them in accordance with local regulations where possible.

Customer service & support

In case of problems, questions or spare part requirements please contact us:
SIENA GARDEN GmbH & Co. KG
Tel. : +49 251 687 - 6040
Email: service@sienagarden.de
www.sienagarden.de
Please have the serial number and a photo of the problem ready.

Importante, conservare per riferimento futuro: leggere attentamente.

Mobili da esterno per uso domestico

Important, to keep for future reference: read carefully.

Outdoor furniture for domestic use

SIENA GARDEN GmbH & Co. KG
Dornierweg 12 | 48155 Münster
Germany | **service@sienagarden.de**
Versione 07/2026 | As of 07/2026
www.sienagarden.de

Informati qui sullo smaltimento del tuo imballaggio:
Find out here how to dispose of your packaging:
www.sienagarden.de/recycling